

**FUNCTION** selector

**FAN SPEED selector** 

RESERVE button

**SET TIMER button** 

CANCEL button

Every time you press the button, fan speed

Use this button to select the operating mode.

Every time you press it, the mode will change

will change as the below sequence.

Use this button to select "ON timer" or

Press this button to enter ON or OFF timer.

Press this button to cancel ON or OFF timer.

as the below sequence.

"OFF timer".

START/STOP button

deflectors.

**SETTING TIME button** 

operation seems unusual.

Use this button to select time for timer.

RESET button

Press this button after battiry change or if

Press this button to start operation.

Press it again to stop operation.

**TEMPERATURE** button

Controls the angle of the horizontal air

the temperature setting.

**AUTO SWING button** 

Use these buttons to raise or lower

# SANYO COOL 風量 風向 ON/OFF 1H TIMER TEMPERATURE SLEEP FUNCTION FLAP FAN SPEED ON TIMER OFF 207-C Small Bentroom

## START/STOP button

Press this button to start operation. Press it again to stop operation.

## **TEMPERATURE** button

Use these buttons to raise or lower the temperature setting.

#### **FUNCTION** selector

Use this button to select the operating mode. Every time you press it, the mode will change as the below sequence

### **FAN SPEED selector**

Every time you press the button, fan speed will change as the below sequence.

#### **OFF TIMER button**

Press this button to set OFF timer. Press it again to cancel.

#### **SETTING TIME button**

Use this button to select time for timer.

#### **OFF TIMER button**

Press this button to turn OFF 1hour later.

## **AUTO** button

AUTO mode direct selection.

## **AUTO SWING button**

Controls the angle of the horizontal air deflectors.

#### ON TIMER button

Press this button to set ON timer. Press it again to cancel.





