



**OFF TIMER button**

Press this button to set OFF timer.

**CANCEL button**

Press this button to cancel ON or OFF timer.

**FUNCTION selector**

Use this button to select the operating mode. Every time you press it, the mode will change as the below sequence.

**AUTO SWING button**

**START/STOP button**

Press this button to start operation. Press it again to stop operation.

**TEMPERATURE button**

Use these buttons to raise or lower the temperature setting.

**ON TIMER button**

Select the turn ON time.

**FAN SPEED selector**

Every time you press the button, fan speed will change as the below sequence.

**POWERFUL Button**

Press this button during operation, cool down or warm up the room quickly.