

START/STOP button

Press this button to start operation.
Press it again to stop operation.

FUNCTION selector

Use this button to select the operating mode.
Every time you press it, the mode will change
as the below sequence.

DEHUMIDIFY button

Dehumidify mode direct selection.

RESERVE button

Use "TIMER" button to select the ON/OFF timer
Use "FORWARD/BACK" button to set the
how hours later turn ON/OFF.

FAN Speed

FAN direction

Hours later

TEMPERATURE button

Use these buttons to raise or lower
the temperature setting.

FAN SPEED selector

Every time you press the button, fan speed
will change as the below sequence.

AUTO SWING button


Controls the angle of the horizontal air
deflectors.

AIR CLEAN button

Use button to start air cleaning operation.

RESET button

Press this button after battery change or if
operation seems unusual.



ON/OFF button

Press this button to start operation.
Press it again to stop operation.

Operation select button

Use this button to select any one of
the operation modes
(COOL → DEHUMIDIFY → HEAT)

DEHUMIDIFY button

Dehumidify mode direct selection.

ECONO COOL button

Use this button to operate COOL
mode with energy saved.

RESERVE button

Use "TIMER" button to select the ON/OFF
timer.

Use "FORWARD/BACK" button to set
how hours later turn ON/OFF.

COOL
DEHUMIDIFY
HEAT
ECONO COOL
Internal Cleaning

TEMPERATURE button

Use these buttons to raise or lower
the temperature setting.

FAN SPEED selector

Every time you press the button, fan speed
will change as the below sequence.

AUTO SWING button


Controls the angle of the horizontal air
deflectors.

AIR CLEAN button

Use button to start air cleaning operation.

RESET button

Press this button after battery change or if
operation seems unusual.



ON/OFF button

Press this button to start operation.
Press it again to stop operation.

Operation select button

Use this button to select any one of the operation modes
(COOL→DEHUMIDIFY→AUTO
→VENTIRATION→HEAT)

Inspection button

Use this button to inspection of Air conditioner

TEST button

Use this button to make a trial run of Air conditioner.

RESET button

Press this button after battiry change or if operation seems unusual.

TEMPERATURE button

Use these buttons to raise or lower the temperature setting.

OFF TIMER button

Select the turn OFF time.

FAN SPEED selector

Every time you press the button, fan speed will change as the below sequence.

ON TIMER button

Select the turn ON time.

AUTO SWING button

Controls the angle of the horizontal air deflectors.